


Parts Information: Transmission Jack 0.5tonne Vertical Model No: 500ETJ.V2



NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.



Parts Information:
Transmission Jack 0.5tonne Vertical
Model No: 500ETJ.V2

1	500ETJ.V2-01	SADDLE
2	500ETJ.V2-02	DUST RING
3	500ETJ.V2-03	O-RING
4	SB-6.4	STEEL BALL 6.4mm
5	500ETJ.V2-05	O-RING
6	500ETJ.V2-06	RELEASE ROD
7	500ETJ.V2-07	BUSH
8	500ETJ.V2-08	SPRING
9	500ETJ.V2-09	RELEASE KNOB
10	GSM58.S	GRUB SCREW M5x8
11	500ETJ.V2-11	PIN
12	500ETJ.V2-12	CYLINDER HEAD
13	500ETJ.V2-13	O-RING
14	500ETJ.V2-14	O-RING
15	1000TRQ.V2-15	OIL FILLER PLUG
16	500ETJ.V2-16	RESERVOIR
17	500ETJ.V2-17	CYLINDER
18	500ETJ.V2-18	PISTON
19	500ETJ.V2-19	O-RING
20	500ETJ.V2-20	PLUG (12mm)
21	SB-9.5	STEEL BALL 9.5mm
22	500ETJ.V2-22	CIRCLIP
23	FWM16.S	FLAT WASHER M16 SINGLE
24	500ETJ.V2-24	BUSH
25	500ETJ.V2-25	SPRING

Item	Part No.	Description
26	500ETJ.V2-26	PUMP UNIT
27	500ETJ.V2-27	PUMP PISTON
28	500ETJ.V2-28	SEAL
29	500ETJ.V2-29	O-RING
30	500ETJ.V2-30	PLUG SCREW
31	500ETJ.V2-31	O-RING
32	500ETJ.V2-32	BUSH
33	500ETJ.V2-33	SPRING
34	500ETJ.V2-34	SPRING GUIDE
35	500ETJ.V2-35	CIRCLIP
36	500ETJ.V2-36	BUSH
37	500ETJ.V2-37	SPRING WASHER
38	500ETJ.V2-38	FOOT PEDAL
39	500ETJ.V2-39	WASHER
40	500ETJ.V2-40	NUT
41	500ETJ.V2-41	PUMP
42	500ETJ.V2-42	SIDE LEG
43	SN12.SD	STEEL NUT M12 DOMED (SINGLE)
44	FWM12.S	FLAT WASHER M12 SINGLE
45	SWM10.SB	SPRING WASHER M10 BLACK(SINGLE)
46	SS1020.S	HEX HEAD SET SCREW M10x20mm SINGLE
47	500ETJ.V2-47	WHEEL,CASTOR (75x10x30x108)