



INSTRUCTIONS FOR:

MOBILE WORKBENCH 2-LEVEL

MODEL NO: **AP1100M**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions and maintained properly, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY

- ☐ **WARNING!** *Ensure Health & Safety, local authority, and general workshop practice regulations are adhered to when using this bench.*
- ✓ Locate bench in a suitable working area.
- ✓ Keep the work area clean, uncluttered and ensure there is adequate lighting.
- ☐ **WARNING!** Use bench on level and solid ground, preferably concrete. *Avoid tarmacadam since the bench may sink into the surface.*
- ✓ Always apply the brakes to the locking castors before using the bench.
- ✓ Keep the bench clean and tidy in accordance with good workshop practice.
- ✓ Keep children and unauthorised persons away from the working area.
- x **DO NOT** place heavy loads on the lower shelf.
- x **DO NOT** use the bench for any purpose other than that for which it is designed.
- x **DO NOT** carry out any work on the bench without the workpiece being adequately secured. Use clamps or a vice (not included) to secure the workpiece (available from your Sealey dealer).
- x **DO NOT** use the bench outside.
- x **DO NOT** get the bench wet, or use in damp or wet locations or areas where there is condensation.
- x **DO NOT** clean the bench with any solvents which may damage the paint surface.
- ☐ **WARNING!** This workbench is heavy and assistance should be obtained before assembly.

2. INTRODUCTION


Sturdy steel construction workbench with a capacity of 300kg. Two shelves that allow unobstructed access. Fitted with two fixed castors, two locking castors and a heavy-duty handle.

3. SPECIFICATION

Model No: **AP1100M**
Size incl. Handle (W x D x H): 1180 x 700 x 830mm
Work Surface (W x D): 1100 x 700mm
Capacity: 300kg





4. ASSEMBLY



Key:

- 1: Bench Top
- 2 Leg Frames (x2)
- 3: Support Brackets (x4)
- 4: Castor Brackets (x4)
- 5: Locking Castors (x2)
- 6: Fixed castors (x2)
- 7: Handle
- 8: Shelf



- 4.1. Place the bench top (fig.1.1) upside on the floor. Use a floor covering to protect the bench top.
- 4.2. Fasten the four support brackets (fig.1.3) to the leg frames using the fixings provided (fig.2).
- 4.3. Fasten the leg/bracket assemblies to the channels welded to the underside of the bench top (fig.3).
- 4.4. Fasten the four castor brackets (fig.1.4) to the legs.
- 4.5. Fasten the two locking castors (fig.1.5) to the legs at one end.
- 4.6. Fasten the two fixed castors (fig.1.6) to the legs at the other end.
- 4.7. Fasten the shelf (fig.1.8) to the crossmembers of the leg frames.
- 4.8. Using two people, turn the bench right way up.
- 4.9. Fix the handle (fig.1.7) to the end of the bench to which the locking castors are fitted.