



**Note:** Part numbers are common to both models except for those items where two numbers are shown.

Item	Part No.	Description
1	GDM120B/01	Base - GDM120B
1	GDM160F/01	Base - GDM160F
2	GDM120B/02	Col. Holder - GDM120B
2	GDM160F/02	Col. Holder - GDM160F
3	GDM120B/03	Washer
4	GDM120B/04	Screw - GDM120B
4	GDM160F/04	Screw - GDM160F
5	GDM120B/05	Col. + Holder - GDM120B
5	GDM160F/05	Col. + Holder - GDM160F
6	GDM120B/06	Rack - GDM120B
6	GDM160F/06	Rack - GDM160F
7-10	GDM120B/07-10	Handle Assembly
11	GDM120B/11	Clamp Bolt
12	GDM120B/12	Gear Shaft
13	GDM120B/13	Screw
14	GDM120B/14	Rack Collar
15	GDM120B/15	Scale Sleeve
17	GDM120B/17	Pin
18	GDM120B/18	Knob
19	GDM120B/19	Feed Handle & Knob
20	GDM120B/20	Handle Base
21	GDM120B/21	Feed Pinion
22	GDM120B/22	Scale
23	GDM120B/23	Set Screw
25	GDM120B/25	Set Screw
26	GDM120B/26	Screw Knob
28	GDM120B/28	Spring
29	GDM120B/29	Rod
34	GDM120B/34	Strip Relief

Item	Part No.	Description
35	GDM120B/35	Cord
36	GDM120B/36	Clamp Bolt
37	GDM120B/37	Screw
41	GDM120B/41	Motor
42	GDM120B/42	Set Screw
43	GDM120B/43	Motor Pulley
44	GDM120B/44	V-Belt
45	GDM120B/45	Screw
47	GDM120B/47	Screw
49	GDM120B/49	Screw
50	GDM120B/50	Screw
51	GDM120B/51	Knob
52	GDM120B/52	Pulley Guard, Upper
53	GDM120B/53	Screw
55	GDM120B/55	Switch
56	GDM120B/56	Pulley Guard, Lower
57	GDM120B/57	Nut
58	GDM120B/58	Spindle Pulley
59	GDM120B/59	Driving Taper Sleeve
60	GDM120B/60	C-Ring
61	GDM120B/61	Bearing
63	GDM120B/63	Screw
66	GDM120B/66	Spring & Cap
68	GDM120B/68	Nut
70	GDM120B/70	Screw
71	GDM120B/71	Nut
72	GDM120B/72	Table
73	GDM120B/73	Washer
74	GDM120B/74	Bearing

Item	Part No.	Description
81	GDM120B/81	Washer
82	GDM120B/82	Screw
83	GDM120B/83	Chuck Key
84	GDM120B/84	Chuck
85	GDM120B/85	Clamp Bolt
86	GDM120B/86	Screw
87	GDM120B/87	Zero Mark
88	GDM120B/88	Table Arm
89	GDM120B/89	Table Bracket
92	GDM120B/92	Gear
93	GDM120B/93	Worm
94	GDM120B/94	Angle Scale
95	GDM120B/95	Spindle
96	GDM120B/96	Arbor
97	GDM120B/97	Wedge
98	GDM120B/98	V-Belt
99	GDM120B/99	Head Frame
102	GDM120B/102	Lock Ring Shaft
103	GDM120B/103	Lock Ring Pulley
104	GDM120B/104	Bearing
105	GDM120B/105	Central Pulley
106	GDM120B/106	Shaft Assembly
109	GDM120B/109	Quill
110	GDM120B/110	Bearing
111	GDM120B/111	Ring