

Universal TPMS Service/Repair Kit

Essential kit for servicing and repairing all TPMS sensors and valves.

This Universal TPMS Service/Repair Kit contains all the tools you would need to service or repair any TPMS sensor or valve.

Features and Benefits

- Solid compact case
- Features a Torque Wrench with a torque range from 2-14 Nm, used for installing TPMS sensor nuts
- The Valve Inserting Tool is easy to use and serves as both a core remover and installer
- The Torque Tool for Valve and Sensor Assembly comes with 3pcs of T10 T15 T20 torx bits
- Ideal to keep in a van or workshop

www.pclairtechnology.com



DRIVEN BY AIR.



Kit contents:

- x1 Torque Wrench 2-14 Nm
- x1 Torque Tool for Valve and Sensor Assembly 0.5 - 3.5 Nm
- x1 Bit holder for Torque Tool
- x1 Splint driver 2mm
- x1 Bit Holder (150mm extension) for Torque Tool
- x1 Torque adjuster for Torque Tool
- x1 11mm Socket
- x1 12 mm Socket
- x1 T10 Star Socket
- x1 T15 Star Socket
- x1 T20 Star Socket
- x1 Tyre Valve Removal Tool
- x1 Valve Inserting Tool Torque 0.25 Nm
- x1 Valve Inserting Tool Torque 0.45 Nm



Part No.	Description
TPMS01	Universal TPMS Service/Repair Kit