



INSTRUCTIONS FOR:  
**MOBILE BIN STORAGE SYSTEM WITH 94 BINS**  
MODEL No: **TPS94**

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



**IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.**

## 1. SAFETY INSTRUCTIONS

### 1.1. GENERAL SAFETY

- ❑ **WARNING!** Ensure Health & Safety, local authority, and general workshop practice regulations are adhered to when using this rack.
- ✓ Locate rack in a suitable work area.
- ✓ Keep the work area clean, uncluttered and ensure there is adequate lighting.
- ❑ **WARNING!** Use rack on level and solid ground, preferably concrete.
- ✓ Keep the rack clean and tidy in accordance with good workshop practice.
- x **DO NOT** use the rack for any purpose other than that for which it is designed.
- ✓ Keep children and unauthorised persons away from the work area.

## 2. SPECIFICATION

Powder coated steel racking with plastic storage bins positioned evenly on both sides. Mounted on heavy-duty castors for mobility.  
Capacity: . . . . . 64 small bins (110 x 160 x 75mm)  
. . . . . 30 large bins (150 x 235 x 125mm)  
Rack Height: . . . . . 1245mm  
Rack Width: . . . . . 940mm  
Rack Depth: . . . . . 500mm  
Weight: . . . . . 33kg



## 3. ASSEMBLY

- 3.1. Attach castors x 4 to the underside of the bottom deck.
  - 3.2. Attach upright supports (1) to bottom deck.
  - 3.3. Connect brace supports (2) to upright supports (1) and bottom deck.
  - 3.4. Attach top (3) to uprights (1).
  - 3.5. Attach cross braces x 7 (only 4 shown on diagram) to the upright support brackets (4).
- NOTE! Ensure all centre support holes on the cross braces are in alignment with each other.**
- 3.6. Attach centre support (5) to cross braces.
  - 3.7. Ensure all fixings are secure.

